

Quick Start Guide

August Car MP3 Player & FM Transmitter with 2GM Memory & Card Reader (CM200)

Thank you for purchasing our August product, please follow the instructions below to use the device.

1. Connect the device with your computer, drag and drop MP3 music files from your computer to the built-in 2GB flash of this device.
2. Plug the device to your car cigarette lighter socket, the device will turn on automatically and start to play the music if there is any stored in the built-in flash.
3. The default frequency of this device is 87.5 MHz, and it will show on the screen of the device. Tune your car FM radio to the same frequency, then you should be able to hear the music from your car audio system.
4. To reset the frequency to what you prefer, press CH- or CH+ to change.
5. During the music playback, use PREV, NEXT or number buttons to select the songs, use PLAY/PAUSE to pause or resume the playback.
6. To change the volume, press and hold PREV or NEXT on the device or use volume buttons on the remote.
7. Press EQ button on the remote to change EQ setting: NORMAL, ROCK, SOFT, JAZZ, or SRS.
8. To play MP3 music from a SD card, insert the SD card to the card slot.
9. The USB port on the device is for transferring music from a computer to the memory in the device and does not support music playback from a USB memory stick.
10. If you would like to send the music from your MP3 player, mobile phone or other audio video player to the car FM radio system, use the 3.5 mm audio cable supplied to connect the device.
11. Please note the above instruction is only intended for reference. August International Ltd reserves rights to revise the product specifications, features and design without notice.
12. For any further queries, please telephone August International Ltd helpline 0870 850 3525 or email service@augustint.com