

# August® User Manual



**CR100**

**Car MP3 Player & FM Transmitter with Card Reader/USB**

## User Manual

Thank you for purchasing this August product, please follow the instructions below to use the device.



- 1 -

1. To play MP3 music from a USB stick, MMC or SD card, insert the card or stick into the card reader or USB port. (Please note the transmitter supports up to 4GB memory cards or USB sticks.)
2. Plug the device into your car's cigarette lighter socket, the device will automatically turn on and start to play any MP3 music file stored on the card or stick.
3. The device's transmission frequency is shown on the LCD screen. Tune your car's radio to the matching frequency to start playback via the stereo.
4. To alter the transmission frequency, use the A- / B+ buttons on the device or CH- / CH+ on the remote control. Changing frequency can help to improve signal quality.
5. The PREV, NEXT buttons can be used to skip forward and backwards through stored tracks and the PLAY/PAUSE button pauses and resumes playback.
6. To set the volume, press and hold PREV or NEXT on the device or use the volume buttons on the remote control.

- 2 -

7. To change EQ settings press the EQ button on the remote to cycle through: NORMAL, POP, ROCK, JAZZ, and CLASSIC.
8. To select a specific song press "Pick Song", 4 dashes (----) will appear, type in the number of the track you would like to play, then press "Pick Song" again to jump to that track. For example: pressing "Pick Song", then pressing number "2" followed by "Pick Song" will start playback of the second song.
9. Pressing and holding the PLAY/PAUSE button switches the playback mode between: Single (repeats the current track continuously), Random (plays all tracks in a random order) and All (plays all tracks alphabetically).
10. To connect your MP3 player, mobile phone or other multimedia player to your car's FM radio, use the 3.5 mm audio cable supplied to connect from your player's headphone socket to the device's 3.5mm audio in.

- 3 -

### 11. Specifications

FM Frequencies Range	87.5 – 108MHz
Input Ports	USB SD/MMC Card Reader 3.5mm audio in
Card Reader	Support SD/MMC card up to 4GB
USB Port	Support USB memory stick in FAT format and up to 4GB
Supported File Type	MP3
Power Input	12 / 24 V

Please note the above instructions are only intended for reference. August International Ltd reserves rights to revise product specifications, features and design without notice.

For any further queries, please telephone August International Ltd's helpline +44 (0)845 250 0586 or email [service@augustint.com](mailto:service@augustint.com)

- 4 -

August International Ltd  
United Kingdom  
Telephone: +44 (0) 845 250 0586  
[www.augustint.com](http://www.augustint.com)