AUGUSt® User Manual

—— EP605 ——

- Bluetooth Headphones
- FR Ecouteurs Bluetooth
- **DE** Bluetooth Kopfhörer
- IT Auricolari Bluetooth
- Es Auriculares Bluetooth

August International Ltd United Kingdom Telephone: +44 (0) 845 250 0586 www.augustint.com

User Manual

Thank you for purchasing the August EP605 Bluetooth Wireless Headphones. This user manual is designed to familiarize you with all the features of this device. Please take the time to read this user manual carefully, even if you are already familiar with a similar product.

Safety

To ensure the safety of you and others, please read the Safety Instructions before using this device. Please do not disassemble the EP605, it can be unsafe and will invalidate the manufacturer's warranty.

Disposal

Please ensure the product and accessories are disposed of in compliance with the WEEE (Waste Electrical and Electronic Equipment) Directive and any other regulations applicable to your country.

Always check with the environment agency and any other relevant authorities for current disposal regulations.

Customer Service

You can contact us by phone on: +44 (0)845 250 0586 or by email at: service@augustint.com should you require further technical support or customer service.

1. Safety Instructions

Storage and Use



Keep this device away extreme temperatures.

the device

When carrying

smoke.



Keep the device away environment.



to maisture dust oil or





this device as part of your luggage please securely stored to avoid impact damage



Never strike device with any sharp object.

Maintenance

Please unplug all leads before cleaning this device.



Wine the device and buttons with a roft cloth



Never wine this device with an or apply cleaning products

2. Main Features

- Wireless Headset for Bluetooth Devices
- Integrated Microphone for Hands-free Calls
- Built-in Rechargeable Battery ■ Micro USB Charging Port
- Range: up to 10m (Class II)
- Bluetooth Version: 3.0+EDR

3. Accessories







- 1) USB charging cable 2) 3 x earbuds
- 3) User manual

4. Part Names and Functions



- 1. Power / Play / Pause / Answer
- 2.+: Volume Up / Next Track
- 3 Volume Down / Previous Track
- 4. Status LED
- 5 Power Socket 6.Microphone



5. Operation

5.1 Switch On / Off

To switch the device on, press and hold the Power button for 2 seconds until the there is a warning sound. Whilst on and unpaired, the status LED flashes blue.

To switch the device off, press and hold the Power button for 3 seconds, the status LED will flash red then turn off

5.2 Bluetooth Connections

To pair with a device, turn the EP605 off, then press and hold the Power button for 5 seconds to enter pairing mode. Whilst in pairing mode, the status LED flashes red and blue

For mobile phones

- 1) Scan for available Bluetooth devices on your mobile phone (see your mobile phone user manual for instructions if needed).
- 2) Select "EP605" from the available devices and confirm connection.
- 3) The status LED flashes blue once per second whilst paired.

Note:

Accessing Bluetooth settings on mobile phones varies for each phone, to find the information for your phone, please refer to its user manual.

■ For computers

- 1) Enable the Bluetooth function on your computer.
- 2) Select "Devices and Printers" from the Control

 Select "EP605" from the available devices, the system will install the driver automatically. Note:

For Windows 98, XP and Vista, a third-party Bluetooth driver is needed (not included).

- 4) The status LED flashes blue once per second whilst paired.
- If the EP605 is not automatically set as your output device, select "Sound" from the control panel then highlight the EP605 and select "Set Default".

Note:

When switched on, the EP605 will automatically reconnect to the last paired Bluetooth device if it is in range.

5.3 Remote Control

The EP605 is able to control the music playing on either a mobile phone or a computer with a Bluetooth connection.

Press the power button to pause or resume music playback.

Press "+" or "-" to increase or decrease the

Press and hold "+" or "-" for 1 second to select the next or previous track.

Note: The remote control is only compatible with devices that support A2DP, please refer to your devices user manual for its A2DP compatibility.

5.4 Hands-free Calling

Whilst connected to your mobile phone, the EP605 will act as a hands-free system for calls.

Press the power button to pick up or hang up a call. Press and hold the power button for 2 seconds to reject the incoming call.

Double press the power button to redial the last called number on your phone.

6. Charging

When the battery is low, the EP605 beeps every 20 seconds and the status LED flashes red and blue to indicate low power. To recharge the battery, use the supplied micro USB cable to connect the EP605 to a powered USB port.

The status LED constantly lights red whilst charging and turns blue once the battery is fully charged.

Note:

- Only use certified USB chargers from branded manufacturers.
- 2) Fully charge the headset before first use.
- 3) If unused for a long period of time, fully charge the battery before use.

7. Specifications

Bluetooth Version	3.0 + EDR
Bluetooth Profile	HSP, HFP, A2DP, AVRCP
Operating Range	Up to 10m
Frequency Response	80Hz - 20KHz
Speaker Output	15mW
Battery	70mAh/3.7V Li-ion Polymer battery
Working Time	Up to 5 hours
Charging Time	About 2 hours
Charging Port	Micro USB
Weight	10g
Dimensions	30 x 15 x 10mm

8. Troubleshooting

- The EP605 will not turn on.
- 1) Recharge the EP605.
- 2) Press and hold the power button for 2 seconds.
- The computer or mobile phone cannot find the EP605.

Confirm the EP605 is in pairing status and within 10 meters of the device.

-6-

■ The computer cannot install the driver for the EP605.

- For Windows 98, XP and Vista computers, a third-party Bluetooth driver is needed (not included).
- 2) For Windows 7 and 8 computers, please update the driver of the Bluetooth module on your computer. For detailed information of your Bluetooth module, please contact the computer supplier.

■ The sound quality is intermittent in Bluetooth mode.

- 1) Please ensure the headset is within 10 metres of your source device.
- 2) Please disable the Wi-Fi on your source device.

■ There is no sound from the headphones.

- 1) Check the volume on both the source device and the EP605
- 2) If the headset is connected to a computer, please check that the headset is set as the
- The mobile phone asks for a PIN code.

The PIN code for the EP605 is 0000.

current audio out device.

9. Warranty

This product is guaranteed for twelve months from the date of the original purchase. In the unlikely event of any defect arising due to faulty materials or workmanship, the unit will be either replaced or repaired free of charge (where possible) during this period. An alternative product will be offered in case the product is no longer available or repairable.

This warranty is subject to the following conditions:

- The warranty is only valid within the country where the product is purchased.
- The product must be correctly installed and operated in accordance to the instructions given in this user manual
- The product must be used solely for domestic purposes.
- The warranty only covers the main unit, and does not cover the accessories.
- The warranty does not cover the damage caused by misuse, negligence, accident and natural disaster.
- The warranty will be rendered invalid if the product is resold or has been damaged by inexpert repairs. The manufactures disclaim any liability for incidental or consequential damages. Please consult our customer adviser before
- returning any product; we are not responsible for any unexpected product returns.

Any faulty product must be kept and returned in the original packaging with all the accessories and the original copy of the purchase receipt.

The warranty is in addition to, and does not diminish, your statutory or legal rights.

Customer Service:

Telephone: +44 (0) 845 250 0586 Email: service@augustint.com

Email: service@augustint.com