

Quick Start Guide

August Car MP3 Player & FM Transmitter with Card Reader/USB (CR150)

Thank you for purchasing our August product, please follow the instructions below to use the device.

1. To play MP3 music from an USB stick or SD card, insert the USB stick or SD card to the USB or card slot. Please note the device supports SD card or USB stick up to 4GB.
2. Plug the device to your car cigarette lighter socket, the device will turn on automatically and start to play the MP3 music if there is any stored in the memory stick or card.
3. The device's current transmission frequency will show up on your screen. Tune your car FM radio to the same frequency. You should be able to listen to music from your car audio system.
4. To reset the frequency to what you prefer, press - / + on the device or CH- / CH+ on the remote to change.
5. During the music playback, use PREV, NEXT or number buttons to select the songs, use PLAY/PAUSE to pause or resume the playback.
6. To change the volume, press and hold PREV or NEXT on the device or use volume buttons on the remote.
7. Press EQ button on the remote to change EQ setting: NORMAL, POP, ROCK, JAZZ, CLASSIC, and COUNTRY.
8. Press and hold PLAY/PAUSE button on the device to change the play mode: Single (play the current music repeatedly), Random (play the music randomly), All (play all music alphabetically), and Folder (play all music from the current folder repeatedly).
9. Please note the above instruction is only intended for reference. August International Ltd reserves rights to revise the product specifications, features and design without notice.
10. For any further queries, please telephone August International Ltd helpline +44 (0)845 250 0586 or email service@augustint.com