

Quick Start Guide

August 10.4" Digital & Analogue TV/Media Player (DA104PF)

1. It is suggested that you use a roof top aerial when scanning for TV channels for the first time, if any signal is detected, the channel information will be saved on the TV, you may then switch back to the portable antenna supplied and change your location to find the best place to receive the signal.

2. When turning on the device for the first time, it will ask you to do the "First Time Installation", if it doesn't, press DVD/DVB to switch to DVB (Freeview TV) mode. Follow the instructions to select "Country" and start the "Auto Scan". Once the scan has finished, press CH+, CH- or EPG to select channels.

3. To search for Analogue TV, press TV on the remote and you should see either "AUTO", "PAL" or "SECAM" at the top right corner of the screen. Press MENU once to enter the first menu to change "Bright", "Contrast", "Colour" and "Language". Press MENU again to enter the second menu to search for channels, change the video system (S-COLOR) between AUTO, PAL and SECAM, and change the sound system (S-SYS) between I (UK), L (France), BG (other European countries) and DK (Russia and Asia countries). Press DOWN on the second menu to select "AUTO-SEARCH", then press RIGHT to start searching for channels.

4. If you have done the first time installation before, and would like to search for Digital Freeview channels again, or if you have moved to a different region and need to scan channels again, press DVD/DVB to switch to DVB (Freeview TV) mode, then press SETUP, press DOWN to select "Installation", press RIGHT to move to "Auto Scan", press ENTER, press LEFT or RIGHT to select the correct "Country", press DOWN to select "Start Scan", then press ENTER to start. Once the scan has finished, press CH+, CH- or EPG to select channels.

5. To play music, photos or video files on a SD card or memory stick, insert the SD card or memory stick to the card slot or USB port, press DVD/DVB to switch to DVD mode, press LEFT or RIGHT to switch between the "Audio", "Photo", "Video" folders and Subtrack, press UP or DOWN to select the file you want to play, press ENTER or PLAY to start playing.

6. Please note the included portable antenna may only be used in areas where signal is very strong. There may be difficulties in receiving signal with the portable antenna in some regions at present, this is due to the fact that Freeview (www.freeview.co.uk) is yet to operate in full power in the UK. The government aims to achieve a full switchover by 2012, which will occur in stages, region by region between 2008 and 2012, at present the quality of Freeview reception varies in different regions across the UK.

As mentioned on the Freeview website, only 73% of the UK population is able to receive Freeview at present and only a small number of households might be able to use a set top aerial at present. This only applies if you live in an area with coverage close to a transmitter, but reception would still be unreliable and they strongly recommend that you use a roof top aerial for good reception.

The reception will be improving along with the progress of the Digital Switchover Program. Reception may also be affected by various factors such as how close you are to transmitters, tall buildings, thick walls, ceilings and weather etc.

7. For any further queries, please telephone August International Ltd helpline 0870 850 3525 or email service@augustint.com