

August®

User Manual EP725



August International Ltd
United Kingdom
Tel: +44 (0) 845 250 0586
www.augustint.com



- EN Active Noise Cancelling Bluetooth Earphones
- FR Écouteurs Bluetooth à Réduction de Bruit Active
- DE Aktive Noise Cancelling Bluetooth Ohrhörer
- IT Auricolari Bluetooth con Cancellazione Attiva del Rumore
- ES Auriculares Bluetooth con Cancelación de Ruido Activa

User Manual

Thank you for purchasing the August EP725 Active Noise Cancelling Earphones. To ensure you experience the best quality sound, please take the time to choose the correct fitting earbuds. This user manual is designed to familiarise you with all the features of this device. Please take the time to read this user manual carefully, even if you are already familiar with a similar product.

Safety

To ensure the safety of yourself and others, please read the Safety Instructions before using the EP725. Please do not attempt to disassemble the device as this may be unsafe and will invalidate the manufacturer's warranty.

Disposal

Please ensure that the product and accessories are disposed of in compliance with the WEEE (Waste Electrical and Electronic Equipment) Directive and any other regulations applicable to your country. Always check with the environment agency and any other relevant authorities for current disposal regulations.

Declaration of Conformity







The Declaration of Conformity can be found on our website at <http://augustint.com/en/declaration/>

Customer Service

You can contact us by phone on: +44 (0)845 250 0586 or by email at: service@augustint.com should you require further technical support or customer service.


1. Safety Instructions

■ Storage and Use

	Do not store or use the device in extreme temperatures.		Do not store or use the device in wet or damp conditions.
	Do not expose the device to dust, oil or smoke.		Avoid dropping or striking the device.
	When transporting the device, store it securely to avoid impact damage.		Do not bring sharp objects into contact with the device.

■ Maintenance

Please unplug all leads before cleaning this device.

	Wipe the device and buttons with a soft cloth.		Never wipe the device with an abrasive cloth or apply detergent, alcohol or chemical based cleaning products.
--	--	---	---


2. Main Features

- Active Background Noise Reduction
- Wireless Connection for Bluetooth Devices
- In-Line Remote for Music and Call Control
- Integrated Microphone for Hands Free Calling

3. Box Contents

 EP725	 Ear Buds	 Power Cable
 User Manual	 Foam Earbuds	

4. Part Names & Functions



1. Noise Cancelling Switch
2. Microphone
3. Status LED
4. Volume Up / Next
5. Power Button / Phone Call Control / Play / Pause
6. Volume Down / Previous
7. Magnetic charging connector
8. Magnetic charging base
9. Charging LED
10. Dual OTG / USB connector

Status LED Meaning

Indication	LED Status
Reconnecting / pairing	Status LED flashing blue (Quickly)
Paired	Status LED flashing blue (Slowly)
Low Battery	Status LED flashing red (Slowly)
Noise Cancelling Activated	Status LED lights white
Charging	Charging LED lights red
Fully Charged (Plugged in)	Off

5. Operation

5.1 Power


Please fully charge the EP725 before first use or if left unused for a long period of time.

To charge, use the power cable to connect the earphones to a powered USB port.

Whilst charging, the charging LED lights red and will turn off once fully charged.

5.2 Turn On / Off

Press  to switch on the EP725. The EP725 will enter reconnection mode and the status LED will flash blue.

Press and hold  for 3 seconds to switch off the EP725. If there is no Bluetooth connection, the EP725 will turn off automatically after 5 minutes.

5.3 Bluetooth Connection

When the EP725 is switched on, it will enter reconnection mode and connect automatically to any previously known device. If no previously connected devices are found, the EP725 will enter pairing mode after 3 seconds.

To connect to a different device, first press and hold the + and - buttons simultaneously for 5 seconds and then turn off the EP725. This will disconnect the existing device. Then, switch the EP725 back on to enter pairing mode.

In pairing mode, the status LED will flash blue rapidly.

- For mobile phones and tablets

1. Scan for available Bluetooth devices on your mobile phone or tablet.
(Please consult the device's user manual for further instructions if necessary.)
2. Select 'EP725' from the available devices and confirm the connection. Some devices require a pin code. If this is the case, please enter the code '0000'.
3. Once successfully connected, the status LED will flash blue.

- For computers

1. Enable the Bluetooth function on your computer.
2. Select 'Device and Printers' from the Control Panel and click 'Add a Device'.
3. Select 'EP725' from the available devices. The computer will automatically install the driver. If a pin code is requested, please enter the code '0000'.
4. Once successfully connected, the status LED will flash blue.

5.4 Noise Cancelling

Use the noise cancelling switch to enable / disable the noise cancelling function. The status LED will light white while noise cancelling is enabled.

5.5 Remote Control

Button	Operation	Function
+	Press / Press and hold	Volume Up
+	Double Press	Next track
-	Press / Press and hold	Volume Down
-	Double Press	Previous track
○	Press	Play / Pause; Pick up / Hang up a call
○	Press and hold	Power on; Power off; reject an incoming call

5.6 Mobile Phone charging (OTG charging)

The power cable allows you to charge the EP725 from your mobile phone.

To do so, first slide the micro USB port out from the end of the cable by pressing down on the slot and pulling outwards as shown in the diagram below.

To push the micro USB port back inside the cable, press the blue catch and push the micro USB port inwards.



6. Specifications

Bluetooth Version	V4.1 with aptX
Bluetooth Distance	10m
Transmission Frequency	2.40GHz-2.48GHz
Support Profile	HSP / HFP / A2DP / AVRCP
Speaker Diameter	Ø13mm
Impedance	32Ω
Speaker Output	10mW x 2
Frequency Response	20Hz-20KHz
SNR	≥90dB
Distortion	≤0.1%
Noise Reduction Level	Up to 20dB (at 100–500Hz)
Battery Type	3. 7V / 80mAh Li-polymer Battery
Bluetooth Working Time	About 6 Hours
ANC Working Time	About 10 Hours
Bluetooth ANC Working Time	About 4 Hours
Charging Time	1-2 Hours
Standby Time	90 days
Net Weight	20g

7. Troubleshooting

Problem	Solution
Won't turn on.	<ul style="list-style-type: none">• Please ensure that the EP725 is charged.
Can't find the EP725.	<ul style="list-style-type: none">• Confirm that the EP725 is in pairing mode and within 10 meters of the device.
Can't install the driver for EP725 on a computer.	<ul style="list-style-type: none">• Update the driver of the Bluetooth module on your computer.
The sound quality is intermittent in Bluetooth mode.	<ul style="list-style-type: none">• Disable the Wi-Fi on your source device.• Ensure that EP725 is within 10m from source device
No sound.	<ul style="list-style-type: none">• Check the volume on both the source device and the EP725.
Can't pair the EP725.	<ul style="list-style-type: none">• Confirm that the EP725 is not paired to another device.• Delete the EP725 from your device's Bluetooth list.• Press and hold the + and - buttons simultaneously for 5 seconds and then turn off the EP725. Then, switch the EP725 back on to enter pairing mode.

8. Warranty

This product is guaranteed for twelve months from the date of the original purchase. In the unlikely event of any defect arising due to faulty materials or workmanship, the unit will be either replaced or repaired free of charge (where possible) during this period. An alternative product will be offered in case the product is no longer available or repairable.

This warranty is subject to the following conditions:

- The warranty is only valid within the country where the product was purchased.
- The product must be correctly installed and operated in accordance with the instructions provided in this user manual.
- The product must be used solely for domestic purposes.
- The warranty only covers the main unit and does not cover the accessories.
- The warranty does not cover damage caused by misuse, negligence, accident or natural disaster.
- The warranty will be rendered invalid if the product is resold or has been damaged by inexperienced repairs. The manufacturers disclaim any liability for incidental or consequential damages.
- Please consult one of our customer service advisers before returning any products. We are not responsible for any unexpected product returns.
- Any faulty product must be returned in the original packaging with all the accessories and the original copy of the purchase receipt.

The warranty is in addition to, and does not diminish, your statutory or legal rights.

Customer Service:

Telephone: +44 (0) 845 250 0586

Email: service@augustint.com

This product is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. The Declaration of conformity may be consulted online at <http://www.augustint.com/en/declaration>.



Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

No Unauthorized Modifications: Do not make any changes or modifications to this product without the prior express written approval of August International Ltd. Any changes or modifications made without express written approval could void the user's authority to operate this product.



For details of further relevant technical standards, please contact us at the address above.