AUGUSt®

User Manual

SWB100



- EN Smart Wristband
- FR Bracelet Connecté
 - Intelligentes Armband
- Braccialetto Intelligente
- ES Pulsera Inteligente

August International Ltd United Kingdom Tel: +44 (0) 845 250 0586 www.augustint.com

Introduction

Thank you for purchasing the August SWB100 Smart Wristband. This user manual is designed to familiarize you with all the features of this device. Please take the time to read this user manual carefully, even if you are already familiar with a similar product.

Safety

To ensure the safety of you and others, please read the Safety Instructions before using this device. Please do not disassemble the product, it can be unsafe and will invalidate the manufacturer's warranty.

Disposal

Please ensure the product and accessories are disposed of in compliance with the WEEE (Waste Electrical and Electronic Equipment) Directive and any other regulations applicable to your country. Always check with the environmental agency and any other relevant authorities for current disposal regulations.

Customer Service

You can contact us by phone on: +44 (0)845 250 0586 or by email at: service@augustint.com should you require further technical support or customer service.

Please fully charge SWB100 before first use. To charge, use the power cable to connect the SWB100 to a powered USB port.



Once fully charged, the LCD screen displays:

The first time you switch the SWB100 on, the LCD screen will display: SET UP press and hold the button for 3 seconds to initialize your device.

2. Compatibility

2.1 Android Compatibility

The SWB100 App is compatible with Android Version 4.3 and above.

To sync, your Android device requires Bluetooth v4.0 and above.

2.2 Apple Compatibility

The August Fit App is compatible with all iPhones released since iPhone 4s with iOS 7.9 and above.

To sync, your iPhone requires Bluetooth v4.0 and above

3. August Fit

3.1 Syncing Activity

The SWB100 will monitor your activity throughout the day. Upload your data to your phone to save and view your progress over time.

To sync your data manually, connect the SWB100 to your phone by Bluetooth, connect your phone to the internet and click on the Activity page.

You can enable Automatic syncing in the settings page, this will sync all data from the SWB100 to your phone continuously.

Note: this will impact the battery life of the SWB100.

3.2 Viewing Activity

The August fit app can show your activity data for steps taken, calories burnt, distance walked and hours slept. Use the Activity screen to view this data on a daily, weekly or monthly basis and to view your progress towards your targets.

3.3 Reminders

To set up a reminder, press on the reminder screen.

Adjust the date time and reminder type, then press Save to sync the reminder to the SWB100.

NOTE: A maximum of 20 reminders can be created.

To turn a reminder on and off, toggle its switch on the reminder screen:

To edit a reminder, press edit on the reminder screen then use to select the reminder to edit or use to delete a reminder.

3.4 Settings

3.4.1 Always-on Sync

Turn on to continuosly sync data from your SWB100 to your phone.

3.4.2 My Profile

Use My Profile to change your personal details and select between metric and imperial measurement.

3.4.3 Goals

Use goals to set your daily targets for steps taken, calories burnt and hours of sleep.

3.4.4 Pre-set Sleep

Set your planned sleep times in here.

3.4.5 Time Format

Select between 12 and 24 hour time display.

3.5 Notifications

The SWB100 can display notifications from your phone, enable notifications through the settings menu and select which notifications you would like displayed.

- Calendar event notification:
- Email notification:
- Missed calls notification:
- Calls notification:

 SMS notification:

 SMS notification:
- Bluetooth disconnection warning:
- Bluetooth disconnection warning:

4. SWB100 Wristband

4.1 Display Screens

Press the button on the SWB100 to cycle through the following screens:

Time, date and battery Steps Taken Distance Travelled Calories Used

4.2 Sleep Mode

To let the SWB100 know that you are going to sleep, press and hold the button for 3 seconds.

Substitution of the screen. To wake, press and hold the button for 3 seconds again.

4.3 Target Display

Once you have achieved a daily goal, (A RCHIEVEL will be displayed on the screen.

4.4 Charging Reminder

The SWB100 will notify you when the battery is below 10% charged. You will not be able to access the display screens whilst the SWB100 is in low charge mode.

4.5 Time Sync

If PLESTICE is displayed on the SWB100 screen, you will need to connect to your mobile phone to update the time.

4.6 Memory Warning

If is displayed on the SWB100 screen, the memory is almost full. Please sync to your phone to avoid losing data.

4.7 Reminders

At the reminder time set, the following icons will display based on the reminder type. Press the button to dismiss the reminder, or it will show again within 2 minutes.

- Sport: 🎝 SPORT
- Sleep: Sleep
- Medicine: Ø MEDICINE
- Wake up: ② LAKE UP:
- User-defined: ♣ REITHOER

5. Specification

Output	3.0~4.2V
Input	5V/100mA
Working Time	120H
Charging Time	1.5H
Polymer Lithium Battery	55mAh
Bluetooth Profile	4.0BLE
Transmission Frequency	2.402G~2.480G
Support System	Android 4.3 or IOS6 or above Support 4.0BLE
Sensor	3D
Product Dimension	240x16.6x10.7mm
Product Weight	22g



6. Warranty

This product is guaranteed for twelve months from the date of the original purchase. In the unlikely event of any defect arising due to faulty materials or workmanship, the unit will be either replaced or repaired free of charge (where possible) during this period. An alternative product will be offered in case the product is no longer available or repairable.

This warranty is subject to the following conditions:

- The warranty is only valid within the country where the product is purchased.
- The product must be correctly installed and operated in accordance to the instructions given in this user manual.
- The product must be used solely for domestic purposes.
- The warranty only covers the main units, and does not cover the accessories.
- The warranty does not cover the damage caused by misuse, negligence, accident and natural disaster.
- The warranty will be rendered invalid if the product is resold or has been damaged by inexpert repairs. The manufactures disclaim any liability for incidental or consequential damages.
- Please consult our customer adviser before returning any product; we are not responsible for any unexpected product returns.
- Any faulty product must be kept and returned in the original packaging with all the accessories and the original copy of the purchase receipt.

The warranty is in addition to, and does not diminish, your statutory or legal rights.

Customer Service:

Telephone: +44 (0) 845 250 0586 Email: service@augustint.com

This product is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. The Declaration of conformity may be consulted online at http://www.augustint.com/en/declaration.



Industry Canada Statement
This device complies with Industry Canada license-exempt RSS
standard(s). Operation is subject to the following two conditions:
(1) this device may not cause interference, and (2) this device
must accept interference, including interference that may cause
undesired operation of the device.



Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to ty to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

No Unauthorized Modifications: Do not make any changes or modifications to this product without the prior express written approval of August International Ltd. Any changes or modifications made without express written approval could void the user's authority to operate this product.



For details of further relevant technical standards, please contact us at the address above.