

August®

User Manual

VGB100



August®

August International Ltd
Rawmec Business Park
Hoddesdon EN11 0EE
United Kingdom
T: +44(0) 845 250 0586
(Carrier Rates Apply)
E: service@augustint.com

EU Distributor:
Daffodil Germany GmbH
Bayernstr. 10
D-30855 Langenhagen
Germany
T: +49 (0) 511 97812978

www.augustint.com

- | | |
|-----------|------------------------------|
| EN | USB 2.0 Video Capture Stick |
| FR | Clé de Capture Vidéo USB 2.0 |
| DE | USB 2.0 Video Capture Stick |
| IT | Video Capture Stick USB 2.0 |
| ES | Grabador de video USB 2.0 |

Use Manual

Thank you for your purchase of this August product. You may be familiar with similar products to this. However, we advise that you read this User Manual carefully. It is designed to help you install and use the VGB100 with ease.

Safety

In order to ensure your safety and the safety of others, please read the Safety Instructions before using this product.

Disposal

Please ensure the product and its accessories are disposed of in compliance with WEEE (Waste Electrical and Electronic Equipment) Directive and any other applicable regulations. Please check with your local authority for regional disposal regulations.

Declaration of Conformity

The Declaration of Conformity can be found on our website at <http://augustint.com/en/declaration/>

Customer Service

Should you need support with this product, please contact our Customer Service Centre:
Telephone: +44 (0) 845 250 0586 (Carrier Rates Apply)
Email: service@augustint.com

Contents

1. Introduction	1
2. Hardware Connections	2
3. Driver and Software Installation	2
4. Honestech	15
5. Troubleshooting	19
6. Warranty	22

1. Introduction

1.1 Overview

The VGB100 video capture stick creates digital videos on your Hard Drive. With S-Video and RGB In, you can capture and edit footage from your camcorder, VCR, DVD player and other video devices. The enclosed software can convert the recorded file to MPEG2, WMV, MP4.

1.2 Features

- Transfer video from VHS to your PC
- Create files in multiple formats
- Create DVDs from your favourite clips
- Capture still images from footage
- Easily share videos on YouTube
- 3-Phono (Composite) and S-Video input
- Compatible with PAL/NTSC/SECAM formats
- USB powered, no external power needed


1.3 System Requirements

- Operating System: Windows 11, 10, 8, 7, Vista, XP
- CPU: P4 1.4GHz or higher
- RAM: 256MB or higher
- Graphics Card: 512MB or higher
- Microsoft DirectX 9.0 or higher
- Sound Card, CD or DVD drive, USB 2.0 port
- 1GB free hard disk space

1.4 Package Contents

- VGB100
- AV Multi-Cable
- Software CD
- Scart Adaptor
- Installation Guide

2. Hardware Connections




3. Driver and Software Installation

3.1 Installing Honestech via Online Download

1. Enter the following address in your web browser:
augustint.com/en/downloadsoft-9.html
2. Click on the "Driver + Software (VHS to DVD 4.0)" line on the right of the screen.
If you have problems downloading, try using another internet browser.
3. Connect the VGB100 USB stick to your computer.
4. Pause your antivirus (including Windows Defender).
5. Open the downloaded file and start the installation
6. Select the language.

VGB100 VHS to DVD



• Click 'Next'

VGB100 VHS to DVD

Welcome

Welcome to the package for **VGB100 VHS to DVD**. This will initialize the Setup program.

Description:

Setup Package for VGB100 VHS to DVD.

Homepage:


www.augustint.com

Press **Next** to install or **Cancel** to exit.



• Please wait whilst the Installation loads

Device driver installation wizard



• Click 'Install'

Windows Security

Would you like to install this device software?



Name: Conexant Sound, video and game controller...
Publisher: Conexant Systems LLC



Always trust software from "Conexant Systems LLC".

Install

Don't install




You should only install driver software from publishers you trust. [How can I decide which device software is safe to install?](#)

If this window does not appear, please check that your anti-virus software is disabled and that the VGB100 USB stick is properly connected.

• Click 'OK'

Device driver installation wizard



OK

• Select the 'Setup' Language

honestech VHS to DVD 4.0 SE - InstallShield Wizard

Choose Setup Language

Select the language for the installation from the choices below.

English (United States)
French (Standard)
German
Japanese
Portuguese (Standard)
Spanish

InstallShield

< Back

Next >

Cancel

• Click 'Next'

honestech VHS to DVD 4.0 SE Setup



Welcome to the InstallShield Wizard for
honestech VHS to DVD 4.0 SE

The InstallShield Wizard will install honestech VHS to DVD
4.0 SE on your computer. To continue, click Next.

< Back

Next >

Cancel

-5-

• Accept the License Agreement

honestech VHS to DVD 4.0 SE Setup

License Agreement

Please read the following license agreement carefully.



(c) Honest Technology. All rights reserved. honestech, the honestech logo, and the honestech products referred to herein are either the trademarks or the registered trademarks of honestech. All other trademarks are property of their respective owners. Information contained herein is subject to change without notice.

Software License Agreement. HONESTECH IS WILLING TO LICENSE THE SOFTWARE TO YOU ONLY ON THE CONDITION THAT YOU ACCEPT ALL OF THE TERMS CONTAINED IN THIS LICENSE AGREEMENT. This is a legal agreement between you (either an individual end-user or an entity) and honestech. By using the software, you are agreeing to be bound by the terms and conditions of the Agreement. If you do not agree to the terms of this Agreement do not install or use the software. Promptly remove the software together with all copies and return the software package and other

☒ I accept the terms of the license agreement

☐ I do not accept the terms of the license agreement

Print

InstallShield

< Back

Next >

Cancel

• Choose where to save files, and click 'Next'

honestech VHS to DVD 4.0 SE Setup

Choose Destination Location

Select folder where setup will install files.



Install honestech VHS to DVD 4.0 SE to:
C:\...\honestech VHS to DVD 4.0 SE

Change...

InstallShield

< Back

Next >

Cancel

-6-

• Click 'Next'

honestech VHS to DVD 4.0 SE Setup

Select Program Folder

Please select a program folder.



Setup will add program icons to the Program Folder listed below. You may type a new folder name, or select one from the existing folders list. Click Next to continue.

Program Folder:

honestech VHS to DVD 4.0 SE

Existing Folders:

Accessibility
Accessories
Administrative Tools
ArcSoft Connect
ArcSoft ShowBiz
CCleaner
Dell
Dropbox
HP

InstallShield

< Back

Next >

Cancel

• Click 'Install'

honestech VHS to DVD 4.0 SE Setup

Ready to Install the Program

The wizard is ready to begin installation.



Click Install to begin the installation.

If you want to review or change any of your installation settings, click Back. Click Cancel to exit the wizard.

InstallShield


< Back

Install

Cancel

• Click 'Finish'

honestech VHS to DVD 4.0 SE Setup



InstallShield Wizard Complete

The InstallShield Wizard has successfully installed honestech VHS to DVD 4.0 SE. Click Finish to exit the wizard.

< Back

Finish

Cancel

3.2 Software Installation

Step 1 :


Insert the VGB100 into your PC/ Laptop. Then, insert the Software CD. Switch off any Antivirus that is running, and then select 'Driver Install' on the Window that loads.

Note : The Software CD is not compatible with a CD Drive. If your PC/Laptop does not have the appropriate drive, you can download the Honestech Software for free at <https://augustint.com/en/downloadsoft-9.html>




Step 2 :


- Click Install
- Accept the required authorisation



Step 3 : Click "OK"



After the Installation has completed, you should see USB 2.0 Audio Capture and USB 2.0 Video Capture in your 'Device Manager'




3.3 Installing the Software Disk

Step 1 : Click on 'Software Install'




Step 2 : Select your preferred language, and press 'Next'




Step 3 : Accept the Licence Agreement, and press 'Next'




Step 4 : Select 'Next,' and continue




Step 5 : Click 'Install'



Step 6 : Click 'Finish' to complete the Installation



The Honestech Logo will now be on your PC/Laptop Home Screen




This PDF document will also be installed.
It corresponds to the user manual of the software.
Please note that some functions are not available.



4. Using Honestech Software

Step 1: Fill in the licence key
It is written on a green label on the CD cover.



HT VHS to DVD 4.0 SE
XXXXXX-XXXXXX-XXXXXX-XXXXXX-XXXX


• Step 2 : Once in the Software, click on 'Options'



Step 3 : Then, make sure the following is selected for
Video and Audio:

Video Device: Conexant Polaris Video Capture
Audio Device: Conexant Polaris Audio Capture


Step 4 : Click 'Settings'




Step 5 : If you are using the Red, Yellow, and White Cables,
select 'Composite'

If you are using the Black Cable, select 'S-Video'

Step 6 : Click 'Control'




Step 7 :
Select 'PAL_I,' and press 'OK'



If you wish to change the Location in which your Captured Videos are saved, please do the following:

- Click 'Options'
- Click on the 'Yellow' Folder that loads
- Select the Location you wish to save to



5. Troubleshooting

No video in the preview screen:

- Close the software
- On your PC/Laptop desktop, right click on the 'Honestech' icon
- Select 'Properties' and 'Compatibility'
- Tick 'Reduced Colour Mode'
- Select '8 Bit' on the line below

Blue Screen Loads:

- Check the USB and Cable Connections
- Check the Scart Adapter is set to 'Output,' AND is plugged into the AV/TV1 Scart Socket
- Check the Source Device is playing correctly

Video Quality is Poor

- See if formats other than PAL_I provide better Video Quality
- Switch to a different USB Port on your PC/Laptop

PC/Laptop does not Recognise USB Stick

- Deactivate any Antivirus/Malware on your PC/Laptop
- Reinsert the USB, and install the Drivers as per the Instructions
- Accept any Terms that load

Selected Device Cannot Be Used

- Click on the 'Windows' Icon, and select 'Settings'
- Select 'Privacy,' and then select 'Camera'
- Make sure 'Allow apps to access your camera' is switched 'On'
- Ensure that 'Camera' is switched 'On' in the list of Apps below

Licence Key is Not Working

- Please ensure that the Digits are spaced out correctly, and that there have been no typos
- If you have made no errors and the Key is still not working, please contact us for help

If you have made no errors and the Key is still not working, please email us over the following

- A Picture of the Licence Key as displayed on the CD Wallet
- A Picture/Screenshot on how it is entered into the Software

6. Warranty

This product is guaranteed for twelve months from the date of the original purchase. In the unlikely event of any defect arising due to faulty materials or workmanship, the unit will be either replaced or repaired free of charge (where possible) during this period. An alternative product will be offered in case the product is no longer available or repairable.

This warranty is subject to the following conditions:

- The warranty is only valid within the country where the product is purchased.
- The product must be correctly installed and operated in accordance to the instructions given in this user manual.
- The product must be used solely for domestic purposes.
- The warranty only covers the main unit, and does not cover the accessories.
- The warranty does not cover the damage caused by misuse, negligence, accident and natural disaster.
- The warranty will be rendered invalid if the product is resold or has been damaged by inexperienced repairs. The manufacturer disclaims any liability for incidental or consequential damages.
- Please consult our customer adviser before returning any product; we are not responsible for any unexpected product returns.
- Any faulty product must be kept and returned in the original packaging with all the accessories and the original copy of the purchase receipt.

The warranty is in addition to, and does not diminish, your statutory or legal rights.

Customer Service:

Telephone: +44 (0) 845 250 0586 (Carrier Rates Apply)

Email: service@augustint.com

This product is in compliance with the essential requirements and other relevant provisions of Directive 2014/30/EU. The Declaration of conformity may be consulted online at <http://www.augustint.com/en/declaration>.

